






































		Code	Description	Qty
1		207348O/A	Flange	1
12		3LI074	Key	1
13		207349A/A	Bearing support	1
14		3VP024	Stud bolt	4
15		3DEA020	Nut	4
16		3RE020	Washer	4
17		204470B	Magnetic plug	1
18		207475B	Breather plug	1
19		207355A/A	Cover	1
20		3VTE004	Screw	4
22		207357F	Gasket	1
23		207356A/A	Cover	1
24		3VTE004	Screw	4
26		204086F	Gasket	1
27		214329H	Shaft	1
28		3AT003	Seal ring	1
29		3GAN060Z	Self-locking ring nut	1
31		3CU055	Ball bearing	1
32		3CU056	Roller bearing	1

33		3AT012	Seal ring	1
34		3AP007	Seal ring	1
35		3VP024	Stud bolt	4
36		3DEA020	Nut	4
37		214328A/A	Pump body	1
38		3VP034T	Stud bolt	2
39		3DEA010T	Nut	2
40		3VP037	Tie rod	12
41		3DEA016	Nut	10
42		218601I	Wear ring	1
43		3NO019	Plug	2
45		215053F	Stuffing-box ring	6
46		214897T/A	Twiner stuffing-box flange	1
47		214308A01	Impeller	1
48		3LI066	Key	1
49		204677T	Spacer	1
50		204834A/A	Diffuser	1
51		218601I	Wear ring	2
53		214962N	Self-locking nut	1
54		214953T	Washer	1
55		204669A	Diffuser shell	1
56		3NO019	Plug	1
57		204005F	O-Ring	1
58		204671A/1A	Suction cover	1
59		218601I	Wear ring	1
60		202306C	Bush	1
61		204838A00	Impeller	1
62		204012N	Foot	1
63		3DEB016	Nut	2
64		214305Q	Bush	1
65		3LI017	Key	1
66		209576Q	Bush	1
67		212446P	Protection	1
68		3VTE115Z	Screw	3
69		3RP001Z	Washer	3
72		218272F	Gasket	1
73		3VCE006	Dowel pin	2